

SCREENSKATE™

SCREEN CLEANER



The ScreenSkate is so convenient and fun to use, before you know it, you'll have the cleanest smartphone, tablet, and computer screens on the block.

Our soft, sturdy microfiber ScreenSkate snaps into an easy-to-grip stingray shape, allowing you to glide it across the screen of your smartphone, tablet, notebook, or computer in one easy, continuous motion. Two integrated magnets hold the ScreenSkate in the perfect position to provide comfortable grip so you can glide flat on the screen and provide even pressure when you clean. Plus, it's square shape means it gets into the corners of your screen easily. Attached to a durable Size #0 plastic S-Biner, you can clip the ScreenSkate to a key chain or computer bag zipper pull and keep it handy throughout your day. Plus, it's the size of a credit card so it easily flattens for convenient storage and easy access anywhere you go.



The ScreenSkate contains two magnets that form the grip area. These magnets will NOT damage your tablet or phone. However, do not place near magnetically sensitive objects such as credit cards, pacemakers, or computer hard drives. Nite Ize assumes no liability for damage to such objects.



- + Convenient, credit card sized screen cleaner
- + Microfiber Cleaning Surface
- + Foldable & Storable
- + Hand Washable
- + S-Biner® clips for easy access
- + Two built-in magnets snap together and provide a comfortable grip to hold the perfect shape for quick and convenient use
- + Folds flat for storage or conveniently clip with the included S-Biner plastic #0
- + Available in 3 colors: Orange, Lime, and Black
- + Dimensions:
Usable Area = 0.9in² | 6.0cm² |
Closed = 1.6" x 2.0" x 0.2" | 40mm x 50.8mm x 5.3mm |
Open = 3.3" x 2.0" x 0.1" | 82.6mm x 50.8mm x 2.0mm (without S-Biner included)
- + Weight: 0.2oz | 7g (with S-Biner attached)



Retail Packaging Dimensions:
5.8"H x 3.3"W x 0.3"D
147.3mm H x 83.8mm W x 7.6mm D

